

DAEWOO DRP-14

Introduction

AM/FM 2BAND RECEIVER

- (1) Telescopic Antenna
- (2) Tuning Indicator
- (3) Tuner
- (4) Tuning Frequency Indicating Window
- (5) Power/Band Switch
- (6) Hand Belt
- (7) Battery Slot (Back)
- (8) Earphones Socket
- (9) Volume Control



Operation Instructions

1. Put two AA1.5V batteries into Battery Slot (7) with correct polarity, and close the lid of the battery slot.
2. Move the Power/Band Switch (5) to the position of FM or AM to receive FM or AM station program.
3. Turn the Tuner (3), and watch the Tuning Frequency Indicating Window (4) and dial pointer select the program which you want to receive.
4. The Tuning Indicator (2) will light up, when the correct station is received and the station signal is sufficiently strong.
5. Turn the Volume Control (9) to your desired volume.
6. When you receive FM station, please pull out the Telescopic Antenna (1) to get the best reception by changing its length and angle.
7. Receiving AM by using the internal magnetic antenna, and you can get the best reception by rotating the direction of the radio.
8. In order not to affect others, please insert the earphones in the Earphones Socket (8) (the speaker inside the radio disconnects automatically), you can listen to the radio by earphones.
9. When you would not like to listen to the radio, please move the Power/Band Switch (5) to the position of OFF to turn off the power.

1. Frequency Range:
AM 530-1600 KHz
FM 88-108 MHz
2. Sensitivity:
AM $\leq 5\text{mV/m}$
FM $\leq 20\mu\text{V}$

3. AM S/N: $\geq 34\text{dB}$
4. Speaker: $\Phi 57\text{mm}/4\Omega/0.5\text{W}$
5. Power: DC 3V, two AA1.5V batteries
6. Output power: $\geq 100\text{mW}$
7. Size: 133 x 72 x 33mm
8. Weight: 170g

Maintenance and safety

1. Do not expose the unit to rain, moisture or extreme high temperature.
2. Do not place the unit near strong magnets
3. Do not attempt to repair this product yourself. Please refer all servicing of this product to a qualified professional.

Declaration of Conformity

Industrias Masats S.L.U. declares product DRP-14 complies with the essential protective requirements and objectives of:
. EMC Directive 89/336/EC

To check the entire declaration of conformity of this model, visit www.electronicaflamagas.com

Warranty

This device has 2 years warranty from the buying date against all manufactured defective problems. Batteries are not related to this warranty. The non-fulfilment of the instructions or cautions use in this manual implies automatically a cancellation of the warranty. It is necessary to show the buying invoice to validate this warranty.

DAEWOO DRP-14

Introducción RADIO AM/FM

- (1) Antena Telescópica
- (2) Indicador de conexión
- (3) Control de sintonización
- (4) Dial
- (5) Conexión/Desconexión/Cambio banda
- (6) Correa de sujeción
- (7) Compartimiento de las pilas
- (8) Toma para auriculares
- (9) Control de volumen



Mantenimiento y Seguridad

1. No exponga la unidad a la lluvia, humedad o temperaturas extremadamente altas.
2. No sitúe la unidad cerca de imanes potentes.
3. No intente reparar este producto por sí mismo. Encargue cualquier reparación a un profesional cualificado.

Declaración de Conformidad

Por medio de la presente, Industrias Masats S.L.U. declara que el DRP-14 cumple los requisitos y objetivos de protección básicos de:
. La Directiva 89/336/EC de Compatibilidad Electromagnética.

Para obtener una copia completa de la declaración de conformidad visite la dirección: www.electronicaflamagas.com

Garantía

Este aparato tiene una garantía de 2 años desde la fecha de adquisición contra todo fallo de fabricación. Esta garantía no cubre las pilas. El incumplimiento de las instrucciones o precauciones de uso implican la pérdida automática de la garantía. Para que esta garantía tenga validez, es necesario presentar el ticket o factura de compra original.

Importador exclusivo: Industrias Masats S.L.U.. www.electronicaflamagas.com

Funcionamiento

1. Abra la tapa del compartimiento de las pilas e introduzca 2 pilas AA. Asegúrese de respetar la polaridad indicada por las marcas (+ y -) del compartimiento de las pilas.
2. Elija la banda AM o FM por medio del selector de banda,
- 3-4 Encienda la radio, el indicador de conexión se encenderá, y seleccione a través del control de sintonización la emisora deseada.
5. Ajuste el volumen en el nivel deseado.
6. Cuando use la radio, estire la antena telescópica para obtener una mejor recepción de la señal.
7. Para sintonizar emisoras en AM, puede mejorar la recepción de la señal rotando la dirección de la radio.
8. Para no molestar a las personas que están a su alrededor, use auriculares (no incluidos).
9. Para apagar la radio, seleccione la posición OFF.

1. Rango de frecuencia
AM 530-1600 KHz
FM 88-108 MHz
2. Sensibilidad
AM $\leq 5\text{mV/m}$
FM $\leq 20\mu\text{V}$

3. AM S/R: $\geq 34\text{dB}$
4. Altavoz $\Phi 57\text{mm}/4\Omega/0.5\text{W}$
5. Alimentación DC 3V, dos pilas AA 1,5V
6. Potencia de salida $\geq 100\text{mW}$
7. Tamaño 133 x 72 x 33mm
8. Peso 170g